

## MLC-S Sprinkler Pipe & Fittings for Concrete Ceilings

## **Universal Casting Cup for Sprinklers in Concrete Floors**

## Installation Cup, Plug, & Cap



Sizes	1" IS(

Tech Data Sheet Contact Tyco for details

The Installation Cup is used in conjunction with the FSC (Flush Sprinkler for Concrete). The corresponding plug is used for fixing (with nails) the position of the cup. For more information on the usage of the Installation Cup see TFP645. The Installation Cup is re-useable. The plug is also available separately (PN 913131004).



MLC-S Installation Cup, Plug and Cap					
Part No.	Dimension	Н	Ø	Туре	Qty
913131110	3/4" ISO, Ø 70mm, h = 56mm	65	70	32	1
1013423-1	An End Cap can be used to avoid concrete splashes	29	32	-	1
PLASTLOKKM7	The Plastic Plug for Metalcap 6 and 7. Must be used in	29	32	_	1

MLC-S-28 Rev: 08-2019